


## Bedroom One - Upstairs



Note: Cable provider and equipment changes often occur. For the latest version of these instructions please visit: <http://www.sacandagarentals.com/HouseGuides/bedroom1.html>.

### To watch cable TV (available via Roku)

1. Using the Insignia remote press & release the power button
2. If you don't see the Roku Home Screen or screen saver press & release the HDMI button
  - Or:
    - Press the input button (middle left)
    - Use the up/down arrows on the central disc to select HDMI-2]Press the "Enter" button (center of the disc)
3. From the Roku home screen use the Roku remote to navigate to the Spectrum app and press "OK"
4. After the app loads, select "Live TV" from the menu at the top of the screen, and press "OK"
5. While in "Live TV" press the right arrow to access the channel guide.
6. Navigate to your desired channel and press "OK"

### NetFlix/Streaming Roku Player

1. Access the Roku home screen as described above
2. Use the Roku remote to select the Netflix app

### Panasonic DVD Player

1. Use the Panasonic remote to power on the player
2. Using the Insignia remote:
  - a) Power on the TV
  - b) press the video button

Or:

  - On the Insignia remote, press & release the Input button
  - Use the disc up/down arrows to select "COMP/AV"
  - Press ENTER
3. Insert a disc into the player & press play
4. Control the DVD functions using the Panasonic remote

### Things to note:

“Pay-Per-View” selections must be billed to your account.

Check cable connections if you are still having trouble.

These notes are as current as possible – we do have guests occasionally “creatively” modify these connections. We ask that you *refrain from doing so*. If a component does not work as described here please contact us.

Version: 04/10/2025